

Fusion Ext-Mic



Controls	Button Control	For details, please see the instructions for buttons.
	Infrared transmission control	Controlled by instructions transmitted through the Quadrant.
Dimensions	132mm×132mm×31mm	
Microphone	Microphone types	Electret microphones
	Pickup distance	3 meters
	Frequency response	120 Hz–16 kHz
Interface	Output	RJ45port for connecting the Quadrant. Support 10-meters transmission.
	Cascading port	RJ45port, capable of cascading up to 2 extended microphones.
Button	Mute button	Disable/Enable the microphones, synchronize the Quadrant mute function
LED lights	Button light	The red light is on when the microphone is disabled, and the green light is on when the microphone is enabled.
	Logo light	The green light remains on when powered on.
Connection method		